


Manual sliding table with initiator



Art. no.: PST-xxx

Usable with: RN/RNE 081 | 151 | 181R,
231/R | 281/R | 331 und RC-30 | HPP-25

Valid from: XX

- Sliding table in workposition is pneumatically locked
- Sliding table is automatically ejected after the riveting
- Automatic running without two-hand operation is possible with the optional protection cover

- Special operation for NOK-pieces possible (e.g. table rests in workposition until confirmation)
- Options: Client specific workholder and drain controller pneumatic sliding table dependent on the used BalTec controller

Standard equipment

- Adjustable damping of the final position
- Adjustable final position with engaging function
- Initiator „table in position“
- Pneumatic interlocking with monitoring
- Pneumatic ejector cylinder

How to get a CE conform Workstation

Operation	Manual retraction of sliding table	Start of riveting process	Automatic extension of sliding table
Pneumatic sliding table without protection cover	✓	two-hand-operation	✓
Pneumatic sliding table with protection cover	✓	automatically	✓



BalTec